



PART NUMBER DESCRIPTION

BOCK MOBILE COMPRESSORS

BOCK04652	FK30 PULLEY (FLYWHEEL) DIA.210MM
BOCK07401	FK30 CLUTCH ASSEMBLY MAGNETIC LA30 24V
BOCK13971	FKX30/235N NORMAL OPERATION(-10C)
BOCK13975	FKX30/325N NORMAL OPERATION (-10C)
BOCK13983	FK40/655N NORMAL OPERATION (-10C)
BOCK14332	FKX20/170TK DEEP FREEZE
BOCK14336	FKX30/235TK DEEP FREEZE
BOCK14338	FKX30/325 TK DEEP FREEZE

BOCK SPARES

	BOCK14332 FKX20/170TK	BOCK13971 FKX30/235N	BOCK14336 FKX30/235TK	BOCK13975 FKX30/325N	BOCK14338 FKX30/325 TK	BOCK13983 FK40/655N	FK40/560NFK40---TKFK30 & 40/---K
Gasket set	80200	80232	80232	80232	80232	80230	80230 80001
Shaft seal set	08002	80123	80123	80123	80123	80023	80023
Valve plate ass	80202	80240/08245	80008/80240	80241	80241	80241	80241 80010
Cylinder cover	06939			03384	03384	03384	03384
Piston & Con rod ass	80211	03384	80250	80111	80226	80111	80110
Piston ass	80220	80109	80107	80105	80225	80105	80104
Con rod ass	80222	80103	08449	08449	08449	08449	08449
Cylinder roller bearing	80118	08449	07755	07755	07755	80118	80118
Front bearing flange		07755	04020	04020	04020	80081	80081
Oil pump ass	80219	04020	80017	80017	80017	80017	80017
Crankshaft ass	80217	80017		80124	80124	80154	80154
Shut off valve -Flange-Discharge	08834	80124		08088	08088	08082	08084
Shut off valve -Flange-suction	08834	08834		08091	08091	08082	08082
Sight glass ass		08088	08552(22mm)/08698(18 mm)	08698	08552	08698	08698
Replcement adaptor set		08698				80022	80022
Oil collecting ring with felt insert				80127	80127	80129	80129
Oil Filter		80127		80076	80076	80076	80076
Safety valve		80076	80076			07940	07940
Ring piston - oil	05389-			06572-	06572-	06572-	06562-
Ring piston - compression	50mm	05390-	05390	65mm	65mm	65mm	60MM
Filter - suction side	05379	55mm	05380	06564	06564	06564	06563
Bolt locking M22 x 1.5	04426	05380	03370	03370	03370	03370	03370
Key- crankshaft		03370		06400	06400	06400	06400
Bolt locking 1/8 NPTF	05671	06400	05672	05672	05672	05673	
Bolt locking 1/4 NPTF	05514	05672		05514	05514	05514	
Base plate	05801	05514					
Base plate gasket						03876	
Gasket set						06721	06721
Valve plate gasket - upper			80232	80232	80232		
Valve plate gasket - lower	06730	80232	06730	06730	06730	06730	06730
Front bearing flange	05674	06730	05695/05675	05697	05697	05697	05696
Gasket front bearing flange	05280	05695		04020	04020	06726	06726
Gasket - oil pump		04020	06085	06085	06085	06165	
Gasket - flange shut off valve - discharge	05081	06085		05094	05094		
Gasket -flange shut off valve - suction	05081	05094	05081	05082	05082	05083	
Gasket -oil pump	05081	05081	05082	05082	05082	05083	
Gasket - oil pump		05082	05094			05094	
O-ring sight glass	06936	05142	05142(18mm)/06352(22 mm)	05142	05142	05142	
O-ring 94 x 2.5	06935						
O-ring 7.5 x 2.0						05169	
O-ring - front bearing flange				05803	05803	05313	
Solder union - discharge				05804	05804	05313	
Solder union - suction		05803	05803	05807	05807	05067	
Gasket solder union - discharge				05807	05807	05067	